



Preparation of VNAV with the first Constraint OBANO 11000 ft.



With nearing TOD VNAV Mode armed and Alt set to FL 11000



At TOD VNAV PATH active



Before OBANO set next ALT 10000, VNAV rest in use



Since no new altitude would be set before reaching, the system announces the reaching of 10,000 ft and would level out.



Set the new next altitude 5000 ft and VNAV will continue the descent



Before the next waypoint, the 5000 ft are approached a little too high, but reached (picture is still a bit deceptive here)



Set 3000 ft



