
## Operations Manual B4 - Q400 V1

Normal Procedures



Figure 12.6 Two-engines Go-around



Revision 39 | Oct 2013 2–117